

A direct acting, two-pipe thermostat is required. Both dampers are normally closed. Hot and cold decks are system pressure independent. Maximum heating and cooling airflow setpoints are constant. When the space temperature is warm, the cold damper is controlling at the maximum CFM setting and the hot damper is closed. As the space temperature drops, the cold damper modulates closed as the hot damper opens. If the space temperature continues to drop, the cold damper shuts off and the hot damper controls at the maximum CFM setting.





CONTROLLER REQUIRES FIELD CALIBRATION AND SET UP UNLESS OTHERWISE SPECIFIED. CONTROLLER RESET RANGE WILL VARY WITH AIR FLOW LIMITS.

------ FACTORY PIPING ------ FIELD PIPING PNEUMATIC AIR CONSUMPTION 1.6 SCFH



DD401R	DRN BY: WDD		DATE:		DRAWING NO.
DD401K			05/02/97		10700
PRESSURE INDEPENDENT PNEUMATIC CONTROLS					
	CKD BY:	DATE:		REV:	19306
THIS DRAWING CONTAINS PROPRIETARY DATA. UNAUTHORIZED DISCLOSURE, REPRODUCTION, OR USE IS STRICTLY PROHIBITED WITHOUT WRITTEN PERMISSION	WAE	10/2	8/08	07	

<sup>&</sup>lt;sup>2</sup> AIR VOLUME WILL DEVIATE FROM CONSTANT AIR FLOW DURING THE MIXING STAGE.