

A reverse acting, two-pipe thermostat is required. Damper is normally open. Optional reheat control will require a normally closed hot water valve or a normally open P.E. switch. All air to room flows through the fan. The thermostat modulates the cold air damper. Unit fan draws air either from the cold duct or the ceiling plenum to maintain a desired room temperature. If warm plenum air fails to satisfy load, an optional electric heater or hot water coil valve is energized. A separate signal (by others) cycles the unit fan and heat for day/night operation thru a normally open P.E. switch.





CONTROLLER REQUIRES FIELD CALIBRATION AND SET UP UNLESS OTHERWISE SPECIFIED. CONTROLLER RESET RANGE WILL VARY WITH AIR FLOW LIMITS.

REFER TO MOTOR WIRING DIAGRAM OR ELECTRIC HEAT DIAGRAM (IF APPLICABLE). FAN P.E. SWITCH TO BE NORMALLY OPEN.

——FACTORY PIPING ----FIELD PIPING —-—FACTORY WIRING

PNEUMATIC AIR CONSUMPTION 1.1 SCFH



	TITLE:	PRESSURE INDEPENDENT PNEUMATIC CONTROLS NANCE		DRN BY:			DRAWING NO.
l	PRESSI			05/03/93		16258	
		RAWING CONTAINS PROPRIETARY DATA. UNAUTHORIZED DISCLOSURE, CTION, OR USE IS STRICTLY PROHIBITED WITHOUT WRITTEN PERMISSION	WAE 08		E: /19/08	REV: 04	10238

HOT WATER VALVE SUPPLIED BY OTHERS. P.E. SWITCH IS INCLUDED IN ELECTRIC HEATER (IF APPLICABLE).