

Webselect VAV Selection/Pricing Quick Start User Guide

for Manufacturer Rep Users

To Select, Price, Quote, Generate submittals and order VAV products, following the following process:

Table of Contents

Step 1 - Start a New Project.....	2
Step 2 - Selecting the First VAV Box in a Project	4
Step 3 – Select More VAV boxes	9
Step 4 – Editing / Changing / Refining the Project Schedule	10
Step 5 - Creating Quotes and Orders	12
Step 6 - Printing Schedules and Submittals	13
Step 7 – Releasing Orders to Factory	14
Step 8 - Adding ZEC510 VAV DDC configurable controllers onto your selection.....	15
Step 9 - Map Gateway, Field User Tool	21


Note: Currently, the tool allows you to select Single Duct “SDR” and “SDL” products only. The other VAV product families of Fan Powered “Series” and “Parallel” and Dual duct will be added in future months. Until then, use the old selection tool to select, price, and order Fan Powered and Dual duct VAV Terminal products.

Step 1 - Start a New Project

1. Log in to Web-Select from the website, (link) www.enviro-tec.com and go to the Web-Select link to sign into the program. If you are having trouble logging in, then contact your Sales Manager.




2. After logging in, you will see the Project list. Add a new project by typing in your Project Name, and click **Add**



3. On the Project list, click **View Schedule**



4. Select **Product Type** to VAV Terminals. (If you see Fan Coil Units as shown below, change it to VAV Terminals). If you do not see VAV Terminals in the Product Type list, then your user account is not set up for that product line and you should contact your Sales Manager.



5. Select the **Model Type** –Single Duct Terminals will be defaulted are currently the only option, but fan powered and dual duct terminals will be added in the future.
6. Now add a line item by selecting the “Add New Line(s)” menu bar. We strongly recommend you leave Qty = 1 for the first line item of a project. See Note below.



*Note: The most efficient way to use the tool is to select the sound attenuation method and all the known options on the first line item completely. Why? Because **whatever you***

select on the first line item will be copied to all subsequent line items of the same model you add the job.

You can always go back and change most options using the Global Option feature, but taking time to fill out everything you know on the first line item will save you significant time.

7. On the first selection, you will be directed to the Unit selection screen (see below).

The screenshot displays the 'VAV Project Selections' software interface. At the top, there is a blue header bar with the title 'VAV Project Selections'. Below the header, there are four tabs: 'Unit', 'Sound', 'Controls', and 'Options'. The 'Unit' tab is currently selected.

The 'Unit Selection' panel on the left contains the following fields:

- Quantity: 1
- Tag: VAV-01
- Model: SDR
- Shipping Cycle: Standard
- Elevation: 2 ft.
- Size: Size 10
- Control Type: Pneumatic
- Max Primary Airflow: 1000 CFM
- Min Primary Airflow: 250 CFM
- Inlet SP: 1.00 in.wg
- Downstream ESP: 0.25 in.wg
- Heat Type: Water heat
- Sound: Calculate
- Unit Arrangement: 1 - LH Controls / LH Coil
- Liner Options: 1" Fiberglass

The 'Heating Coil - Water' panel on the right is divided into two sections:

Air Side Data

- Method: LAT
- Heating Air Flow: 250 CFM
- Entering Air Temp: 55.0 °F
- Leaving Air Temp: 90.0 °F
- Capacity: 0 Btuh
- Rows: 1 row
- FPI: 10
- Circuits: One circuit

Water Side Data

- Entering Water Temp: 180.0 °F
- Leaving Water Temp: 0.0 °F
- Water Flow Rate: 0 gpm
- Max WPD: 10.00 ft.
- Glycol Type: None

At the bottom of the interface, there are three buttons: 'Select', 'Cancel', and 'Show Diagnostics'.

Step 2 - Selecting the First VAV Box in a Project

Note: The program selects, configures and prices VAV boxes all at once so when you price a box, the engineering rules are checked at the same time.

1. On the **Unit screen**, visually scan each input field and enter those fields that are blank and you can also edit/change any of the default field values that appear. Remember, values you enter on the first selection will carry over to all subsequent line items (with the exception of Box Tag and Min and Max airflow (CFM's)).
 - a. Pick your **Shipping Cycle** (this will affect the options that are available)
 - b. For **Size**, you can pick a specific box inlet size, or you enter “Select All Sizes” and let the program show you a choice of sizes for the airflows and pressures you entered.
 - c. Next enter both **Max and Min Primary airflows (CFM's)**. These are required to perform selections, calculate pressure drops, and perform sound calculations.
 - d. Enter the **Inlet and Downstream ESP pressures**. VAV systems are typically designed by engineers with the same inlet pressure drop for all VAV boxes. Typical values are 1.0 or 0.75. Sometimes, the engineer schedules a maximum pressure drop of 0.50 rather than an inlet and downstream pressure, you can enter an Inlet Pressure of 0.75 and a downstream of 0.25 ($0.75 - 0.25 = 0.50$) to achieve the same result.
 - e. Select **Control Type** (it affects the available options and control sequences required for pricing).
 - f. Select **Heat Type** if you have an electric or hot water heater. Additional fields related to the heat type selected will appear. The input fields are self explanatory.
 - i. **Electric Heat Tips for Reps:** Typically, the engineer will specify the desired kW (kilowatts) and LAT (leaving air temperature). Choose the Method = kW. The program will choose the entered or the next higher available kW and calculate the related LAT temperatures.
 - ii. **Hot Water Tips for Reps:** Typically the engineer would like you to match their water flow and capacity. In this case, choose Method = GPM and enter the desired GPM. Pick Rows and Circuits = “Pgm Selects” (program selects) and the program will show the various combinations of resulting capacities available to choose from for the specific box and coil combinations.
 - g. **Unit Arrangement** is required for pricing, and can be changed later prior to ordering by using the “Global Options” feature (see below).

The screenshot shows a software interface with a light green background. At the top, there are two labels: "Unit Arrangement" and "Liner Options". To the right of "Unit Arrangement" is a dropdown menu with a downward arrow. The menu is open, showing a list of options: "-- Select --", "-- Select --", "1 - LH Controls / LH Coil", and "3 - RH Controls / RH Coil". Below the dropdown menu, there are two buttons: "Next" and "Return to Schedule...".

- h. **Liner Options** is required for pricing, and can be changed later prior to ordering using the “Global Options” feature (see below).

2. Click Next to go to the **Sound Screen** (see Figure 1 below).

- a. Select **Method**.

- i. The “**Default**” sound method follows AHRI-885E which is the industry standard for VAV box attenuation. Normally, you would use these defaults unless the consulting engineer specifies different attenuation factors for the job (typically specified at the bottom of their schedule or in their specifications).
- ii. The “**Calculate**” method allows you to fill in exact attenuation factors to calculate the attenuation (this feature is mainly designed for consulting engineers that have a have special attenuation requirements for reading rooms, classrooms, or sound booths).
- iii. “**None**” sets the attenuation values to zero (which would be used for placing the box in a room with no ceiling and no discharge ductwork and will result in higher room NC).
- iv. “**Manual**” allow you to edit each attenuation number on this screen. Use this method if the engineer specifies fixed attenuation numbers in their specification or schedule.

	2	3	7
Rad.	18	19	36
Dis.	24	28	39
			53
			59

AHRI-885 Note
These attenuation values are the default (catalog) attenuation values based upon ARI-885 Appendix E and cannot be changed. The values change based upon airflow through the terminal box as described in the standard.

NOTE:
Changes in the sound method or attenuation values will not be reflected in the Possible Selections table until “Select” is clicked.

Static Override
 Use Non-Actual Static 0 in.wg

NOTE:
Static Override applies only to sound calculations, and does not affect the box inlet static pressures entered on the Unit screen.

Figure 1.0: Sound Screen Example

3. Click Next to go to the **Controls Screen**
 - a. Select a **Controls Type** on the Unit or Control Screen.
 - b. For “**Mount & Wire in factory**”, “**Pneumatic**” or “**Analog Electric**” control types, you must select a control sequence to properly configure a unit and obtain a price. Select the options on the left and click **Get Sequences** to help you select the desired control sequence. Note that even if you do not yet know the Controller brand or sequence, you could select a temporary and non-specific sequence by selecting the “**GENERIC**” sequence. You can change the sequence later in the Global Options feature prior to ordering. NOTE: The “**GENERIC**” sequence is just that...i.e. a Generic non-specific and non-valid sequence, but it will allow you to receive a ballpark list price for factory mount and wire of a general (generic) type of DDC controller. A Generic sequence is not allowed for Ordering and as such and prior to final pricing to your customer the user should “confirm” the brand and type of DDC controller that will be requested for mounting and wiring to the VAV Terminal Unit. To achieve this, the user is required to select the specific type, brand and functionality of the controller. These selections can be made on the Controls Screen.
 - c. For “**Field DDC**” or “**Pneumatic field mounted controls**”, you do not need to select a sequence and no price will be added for providing a sequence.

4. Click Next to go to the **Options Screen** (see Figure 2.0 below)
 - a. Select one or more options you desire for the selection. Many times, these options are specified in the engineering specifications and in the engineer’s schedule.
 - b. Click **Validate Options** button to check if the options selected are valid. Read the diagnostic message results and make changes if necessary. A set of options is valid when “Options Valid” is shown in the results. Again, the options you select here will be copied to other boxes of the same model automatically so pick the options on this first selection.
 - c. Once you get valid options, click **Select**




Figure 2.0: Options Screen Example

5. Once **Select** is clicked, the program will perform the engineering calculations, configuration, and pricing calculations.
 - a. If a Unit size is selected, you will see the results if valid
 - b. If Unit Size = “Program Selects” is selected, then each VAV box size will be attempted to meet the entered parameters. Those box sizes that pass the selection rules (airflow and pressure drop calculations), will be displayed as possible selections.
 - c. Hover your mouse over the information icon “” to see the color code of the results. A “Green” circle indicates “performance and options are valid”. See color legend below for other color circles and their indications (see below).

Results						
Select		Size	Price	Max CFM For Size	Max CFM	Min CFM
<input checked="" type="checkbox"/>		04	\$202	250	250	30

* "-" signifies as NC value (radiated or discharge) that is less than 10

Image Legend

-  Performance and Options are Valid
-  Performance Valid | Failed Options Validation
-  Failed Performance Validation

- If resulting box selections and output parameters meet your specification, then user would check the box to left of specific selection and next click **“Save and New”** to add the VAV box to the users project schedule and begin entries for the next VAV box(es) on your schedule.

Note: Save and New, will save your current selection to the Schedule/Grid and will then open up to the Unit Screen for the next box selection(s).

Save – will save your selection

Save and Return to Schedule – will save your current schedule and next take you to the summary schedule screen (see below).

Select	i	Results							Sound			Radiated Sound Power					Discharge Sound Power						
		Size	Price	Max CFM For Size	Max CFM	Min CFM	Min in.wg	Actual in.wg	Rad NC	Dis NC	Atten.	OB2	OB3	OB4	OB5	OB6	OB7	OB2	OB3	OB4	OB5	OB6	OB7
<input checked="" type="checkbox"/>	●	05	\$202	350	300	60	0.01	0.75	15	-	AHRI-885E	51	48	38	32	28	28	58	55	50	48	42	42
<input type="checkbox"/>	●	06	\$202	530	300	60	0.04	0.75	-	-	AHRI-885E	49	46	37	31	27	26	54	54	48	46	41	41

* "-" signifies as NC value (radiated or discharge) that is less than 10



Step 3 – Select More VAV boxes

After the first selection is made, you can add more boxes to the job by continuing to enter them in the Unit input screens or on the Project Schedule view screen.

1. Enter the airflow, size (or Program Selects), and Heat Capacity (or GPM) for all subsequent boxes in the job on the Unit Screen. All the other choices will be the same as your previous selection.

*Note: After the first selection is selected, the VAV tool is designed to only require a couple of inputs on the Unit screen (such as the Airflows, Size, and Heat capacity) and then click **Select**. Therefore, you typically do not need to click the Control, Sound, or Option screen on subsequent selections unless these options change by box (they typically do not).*


It may take a couple of minutes to make all the choices on the first box, but it will take only a couple of seconds for adding more box selections.

You can also change the Arrangement later (just prior to ordering) using the Global Options feature.

Step 4 – Editing / Changing / Refining the Project Schedule

Displaying Data Using the VAV Project Schedule

There are different display options for the project schedule (see below).



1. **Product Type** displays the line items associated with Fan Coil Units, Belt Drive Blower Coils, or VAV Terminals.
2. **Model Group** displays the line items associated with Single Duct, Series Fan Powered, Parallel Fan Powered, or Dual Duct boxes.
3. Selecting a Heat Type will filter the line items based upon their heat types. The selection of “All” will display all heat types.
4. **View**
 - a. Summary view is designed for the basic information and to see what quotes and orders line items are assigned to.
 - b. Takeoff View is designed to view more engineering data as well as displaying some additional common options.
 - i. Quick is for minimal input – note – the program is just picking defaults in the background.
 - ii. Full is to display the full engineering schedule and allow the user with additional detailed editing.
 - c. Controller View displays fields related to help you view/edit the Arrangement and location of the VAV box (typically specified just prior to ordering units)

Editing Inputs Using the VAV Project Schedule

Once you have built your schedule using the steps above, you can add/edit/update line items within the grid without having to go to the input screens. You may find it best to pick the View as “Takeoff View”, pick Level as “Full” and select a heat type.


VAV Project Schedule																
Unit Data													General Heating Data			
Qty	Tag	Model	Unit Size	Heat Type	Max	Heat	Total Price	Arrangement	EAT	LAT	KW					
1	VAV-01	SDR	10	Water	1000	250	\$642	1 - LH Controls / LH Coil	55.0	90.0	0.00					
1	VAV-01 - 6	SDR	08	Electric	472	236	\$698	1 - LH Controls / LH Coil	12.8	32.2	1.50					
1	VAV-01 - 7	SDR	08	Electric	847	159	\$732	1 - LH Ctl's / LH Coil	41.0	59.0	1.00					

1. For editing most engineering inputs and some common options, click the **Edit** icon. (Move your mouse over the icons to see a pop-up description of each icon)

After you make your changes to that line item, click the Save icon to save the changes, perform the selection, and check the rules (see below).


VAV Project Schedule													
											Unit Data		
<input type="checkbox"/>	Valid	Disp Seq			Qty	Tag	Model	Unit Size	Heat Type	Max	Min	Heat	Total Price
<input type="checkbox"/>		1			1		SDR	05	None	300	60	0	\$202
1 Edit Select Select-Summary													

- For editing most options for multiple line items at once, select the line items you wish to change (or do not select any for all), and click the **Global Options** button above the grid (see below).



Copying, Deleting, Moving Line Items


Select the line items you wish to copy, delete or move by clicking the leftmost checkbox on the VAV Project Schedule. To select all, click the check box at the top of the line items (see below).



- Copy To** → – You may copy one or more line items to create new line items in this project. You may also copy line items to another active project (great for copying a template project to a new project)
- Move To** → You may move line items from one project to another project
- Delete** will permanently delete the selected line items from this project. You cannot delete line items that have been added to an order. You must remove them from the Order, and then delete them. Once the order is released, the line items cannot be deleted.
- Auto Tag** allows you to select one existing line item, and create duplicates of that line item. Sales reps will do this when an engineer specifies one (1) VAV-01 on their schedule, but there are, say 10 VAV-01's on the job. The sales rep can create a small schedule for take-off and pricing purposes, then use Auto tag to copy the (1) VAV-01 ten (10) times while specify the location of many boxes for ordering purposes.


Step 5 - Creating Quotes and Orders

You may create a quote prior to creating an order, or just create an order directly without creating a quote (see below).



The screenshot shows the 'Selected Items' section of a software interface. It features a table with three rows of buttons: 'Order --->', 'Quote --->', and 'Print --->'. Each button is followed by a dropdown menu. The 'Quote' dropdown menu is circled in pink. To the right of these buttons are 'Copy To --->', 'Move To --->', and 'Delete' buttons. Further right is a 'Qty.' field with the value '1' and a dropdown menu showing 'VAV Test Sample'. Below this is another 'Selected Items' header with buttons for 'Submittal/Other Documents', 'Print Schedule', and 'AutoTag'. At the bottom, there are version numbers: 'Current Pricing Data Version: 1.0.0' and 'Current Selection Data Version: 1.0.0', along with a note: 'List prices are valid for 30 days from the Date Priced.'

To create a quote, select the line items to add to the quotes (or select all), and click the Quote button below the grid. A default quote name will be assigned. If you do not select any line items, the program assumes you wanted all line items that are not already assigned to a quote (see below).




The screenshot shows a grid of line items. At the top, there is a button 'Add New Line(s)' and a 'Qty to create:' field with the value '1'. Below this is a table with columns: 'Valid', 'Disp Seq', 'Qty', 'Tag', and 'Model'. The first row is highlighted in light blue. The first checkbox in the 'Valid' column is circled in pink.

Valid	Disp Seq	Qty	Tag	Model
<input checked="" type="checkbox"/>	1	1	SDR	SDR
<input type="checkbox"/>	2	3	SDR	SDR
<input type="checkbox"/>	3	1	SDR	SDR
<input type="checkbox"/>	4	2	SDR	SDR
<input type="checkbox"/>	5	2	SDR	SDR

You may have more than one quote per job, but a line item can only belong to one quote.

Enter your multiplier and other quoting information on the Quote Worksheet. You may combine FCU and blower coil units on a single quote.

Click “Save / Calculate” to save the quote for later editing. You may re-select and re-price line items in a quote. The quote amount will adjust the next time you save the quote (see below).



The screenshot shows two buttons: 'Save / Calculate' and 'View Summary / Create Order'. The 'Save / Calculate' button is circled in pink.

Click **View Summary / Create Order** to review the quote line items and Create the Order. You cannot combine FCUs and VAV Terminals in a single order (see below).



The screenshot shows two buttons: 'Save / Calculate' and 'View Summary / Create Order'. The 'View Summary / Create Order' button is circled in pink.

To print a quote or order, click the **Submittal/Other Documents** button (see below).

Additional help is found by clicking the question mark icons on the quoting and ordering forms

Step 6 - Printing Schedules and Submittals

The screenshot shows a software interface with a blue header bar labeled "Selected Items". Below the header, there are three columns of buttons: "Order -->", "Quote -->", and "Print -->". To the right of these buttons are dropdown menus for "New Order", "New Quote", and "Selection Summary". Further right are buttons for "Copy To -->", "Move To -->", and "Delete". A quantity field "Qty.: 1" and a dropdown menu "VAV Test Sample" are also visible. Below this section is another "Selected Items" header, followed by three buttons: "Submittal/Other Documents", "Print Schedule", and "AutoTag". The "Print Schedule" button is circled in red. At the bottom, there is text: "Current Pricing Data Version: 1.0.0", "Current Selection Data Version: 1.0.0", and "List prices are valid for 30 days from the Date Priced."

Click Print Schedule to print engineering project schedules and export to Excel. The line items will be grouped by Model type and heat type, resulting in multiple schedule files (see below).

These Excel spreadsheets can be then imported into AutoCAD drawings by consulting engineers and contractors.

Click Submittal/Other Documents to create job submittals, quote summary, and ordering reports can be created.

The screenshot shows a software interface with a blue header bar labeled "Submittal Options". Below the header, there are three main sections: "Submittal Documents", "Quoting", and "Ordering". Each section has a checkbox and a dropdown menu. The "Submittal Documents" section includes: Cover Page, Project Schedule, Arrangement, Dimensions, Performance, Sound, VAV Submittal Form, and Other Information. The "Quoting" section includes: VAV Quotation and VAV Quote Pricing Summary. The "Ordering" section includes: VAV Order Pricing Summary and VAV Order Entry Form. To the right of these sections is a "Links" section with: VAV Product Information and VAV Drawings. At the bottom, there are two buttons: "Preview" and "Return to Schedule".

Note: Submittals, Quoting and Ordering forms can take several minutes to generate because they are re-checking the configuration and pricing on the line items for you. Please be patient. You may minimize your browser window while this work is being done by the server.

You are not required to print your orders. Orders will be processed electronically by the Order Entry department when you complete Step 7.

Also, Pick One. Do not select Submittals, Quoting, and Ordering at the same time and click Preview. This will take significant amount of processing time (up to 30 minutes) to generate all these reports and may slow the tool for other users.

Step 7 – Releasing Orders to Factory

To Release an Order to the factory, create an Order as described in Step 5, fill in the Order form, click **Save/Hold for Release** button.

Now select the line items to be release to the factor and click **Release Selected Line Items** button (see below) to preview the release.

Items displaying a Release Number below are ready to release by clicking the Select check box. If no Release Number appears, add items to the release by checking items and clicking the Release Selected Line Items button.

Total Units (all models): 1

ORDER LINE ITEMS FOR ORDER:							
Select	Line #	Release #	Release Status	Line Item Tag	Model Name	Quantity	Unit Price
<input checked="" type="checkbox"/>	28	1	Hold For Release	VAV-06	SDR	1	\$600.00

Release Selected Line Items

Add Selected To --> **Release #** 1 [Make Additional Releases](#)

The final step to submitting your order for production is to click **Submit Release to ETI** button at the bottom of the release screen.

Special Instructions

Carrier To Call 24 Hrs. Before Delivery

Phone # Mark PO#

Notes

* = Required Field

Clicking this will send an email to the order entry department and a confirming email to your Webselect email account on file. The Order Entry department will process your order. Note that you can create more than one release for a given order form

If you would like a PDF or paper copy of your order for your files, you can click the **Preview Consolidated Order** button or see Step 6 instructions for printing order forms. There is no need to email or fax this order form to the factory.

Step 8 – Selecting VAV DDC Configurable Controllers and Thermostats and Discharge Air Temp. sensor, within Web Select.



ZEC510 DDC VAV Controller

Variety (5) models and offerings of T’stats

Follow through normal steps of “adding a line” of vav terminal unit.

ENVIRO-TEC Site Map Help Web-Select

All Projects [Project Name] Project info Users Quotes Orders > Product Schedule

Product Type: VAV Terminal Model Group: Single Duct Terminals Heat Types: All View: Summary View Show: 50 lines Schedule: Custom F

Add New Line(s) Qty to create: 1 Update Tag/Qty

VAV Project Schedule																		
Unit Data																		
Valid	Disp Seq	Unit	Select	Selection Summary	Tag	Qty	Model	Unit Size	Heat Type	Max CFM	Min CFM	Inlet SP	Min SP Req.	Down SP	Heat CFM	Total Price	Order Name	Quote Name
<input type="checkbox"/>	X	2				1	SDR	-		0	0	0.00	0.00	0.00	0	\$0		
<input type="checkbox"/>	✓	3				1	SDR	04	None	250	35	1.00	0.01	0.25	0	\$754		
<input type="checkbox"/>	X	4				1	SDR	04	None	250	35	1.00	0.01	0.25	0	\$754		

Selected Items

Order ---> New Order v Copy To ---> Qty.: 1 Google v

Quote ---> New Quote v Move To --->

Print ---> Consolidated Sel Summary v Delete

Selected Items

Submission/Other Documents AutoTag

Current Pricing Data Version: 1.0.19
Current Selection Data Version: 1.0.0

Next, from the “UNIT” tab, enter in all your normal VAV unit parameters for cooling and heating CFM, and also select the Controls Type of “Factory DDC”, option. This option indicates the selected solution will include a DDC VAV (ZEC510) controller from the factory and this option to be factory mounted, wired, and configured to Users entered VAV parameter settings (i.e. to entered min/max CFM values, etc). Also, next enter in your vav units Min/Max CFM and Heating CFM values and parameters, etc.

Next, move to the “CONTROLS” tab, to make your controller and sequence selection.

Next, select your type of Controller...the ZEC510 (has standalone and/or BACnet communication and networking capability) or ZEC500(for non-communicating and non-networking projects).

Unit Sound **Controls** Options

Control Type: Factory DDC

Instructions: Select the Control Group Options below. If you select control options, the available sequences will shorten when "Get Sequence(s)" is clicked. Select a control sequence from the list after "Get Sequence(s)" has been clicked.

Controller: -- Select --

Heat method: ZEC500, ZEC510

Transformer:

Next, select your Heating type, and click on upper right area for "GET SEQUENCE", and then click on the filtered sequence to lock it in, by it being "bolded" in the Selected Sequence: section.

Unit Sound **Controls** Options

Control Type: Factory DDC

Instructions: Select the Control Group Options below. If you select control options, the available sequences will shorten when "Get Sequence(s)" is clicked. Select a control sequence from the list after "Get Sequence(s)" has been clicked.

Controller: ZEC510

Heat method: No Heat, Modulating HW Valve, Staged Electric Heat, Proportional Electric Heat

Transformer:

Get Sequence(s) Selected Sequence:

No control sequence has been selected. Please choose a sequence to ensure a complete selection.

- Select --
- SDC-ZEC101 - SDC-ZEC101_non-communicating
- SDC-ZEC102 - SDC-ZEC102_non-communicating
- SDC-ZEC103 - SDC-ZEC103_non-communicating
- SDC-ZEC104 - SDC-ZEC104_non-communicating
- SDC-ZEC201 - SDC-ZEC201_BACnet communication
- SDC-ZEC202 - SDC-ZEC202_BACnet communication
- SDC-ZEC203 - SDC-ZEC203_BACnet communication
- SDC-ZEC204 - SDC-ZEC204_BACnet communication

After selecting your Controller type, and Heat method, next select "get sequence". This will filter down to match up with available sequence(s) to your entered control parameters.

ENVIRO-TEC Site Map Help Web-Select

Project Name: Google Tag:

Unit Sound **Controls** Options

Control Type: Factory DDC

Instructions: Select the Control Group Options below. If you select control options, the available sequences will shorten when "Get Sequence(s)" is clicked. Select a control sequence from the list after "Get Sequence(s)" has been clicked.

Controller: ZEC510

Heat method: Staged Electric Heat

Transformer:

Get Sequence(s) Selected Sequence:


No control sequence has been selected. Please choose a sequence to ensure a complete selection.

- Select --
- SDC-ZEC101 - SDC-ZEC101_non-communicating
- SDC-ZEC102 - SDC-ZEC102_non-communicating
- SDC-ZEC103 - SDC-ZEC103_non-communicating
- SDC-ZEC104 - SDC-ZEC104_non-communicating
- SDC-ZEC201 - SDC-ZEC201_BACnet communication
- SDC-ZEC202 - SDC-ZEC202_BACnet communication
- SDC-ZEC203 - SDC-ZEC203_BACnet communication
- SDC-ZEC204 - SDC-ZEC204_BACnet communication


Screen shot shows results of filtered sequences, upon clicking on “get sequence”.



Next click on the chosen controller sequenc, and then the sequence gets selected and “bolded” text shows up in the area to right of “Selected Sequence:”.



Next, go to the OPTION tab, and select your “Thermostat”. Notice available information on available Thermostats by hovering your mouse over the “I” info bubble icon....see next few screen shots following.



Secondary fusing of transformer

Transformer

Transformer Number

Primary Voltage

Trans VA

Thermostat

Discharge Air Sensor

Mount and Wire, Field Control

Electronic actuator

Control enclosure

List Price

\$0.00

\$0.00

The info bubble displays a matrix of available thermostats, with information of options for each thermostat, and also a photo on the specific stat highlighted in yellow.

Note: Selecting your Thermostat results in the thermostat to be provided in its box and within the controls enclosure, loose, and to be field connected to your VAV DDC Controller.

Primary fusing of transformer

Secondary fusing of transformer

Transformer

Transformer Number

Primary Voltage

Trans VA

Thermostat

Discharge Air Sensor

Mount and Wire, Field Control Options

Electronic actuator

Control enclosure

Thermostats

Model	Product Code	Size (mm) 11 x 11	Vertical (Wall- Mount (WB) or Surface Mount (SM))	Logo T / R	LCD Display Y / N	Thermostat Adjustment Setpoint Digital (Set) Whisper/Gentle Start (WGC) Setpoint Publication (Pb)	Occupancy Override * Button, Pin Occupancy Sensor	IFC Toggle	Fan Control	Socket Terminals (ST) or Modular Jack (MJ)	Address Settable	VAV Featuring Feature
B7003	NS-8T7003-2	4-3/4" x 3-1/8" (120 x 80)	WB, SM	No	Yes	Set	Yes/No	Yes	No	ST	Yes	No
J7002	NS-8T7002-2	4-3/4" x 3-1/8" (120 x 80)	WB, SM	No	Yes	PB	Yes/No	Yes	No	ST	No	No
J7003	NS-8T7003-2	4-3/4" x 3-1/8" (120 x 80)	WB, SM	No	Yes	PB	Yes/No	Yes	No	ST	Yes	No
N7003	NS-8T7003-2	4-3/4" x 3-1/8" (120 x 80)	WB, SM	No	Yes	N/A	No/No	No	No	ST	Yes	No
P7002	NS-8T7002-2	4-3/4" x 3-1/8" (120 x 80)	WB, SM	No	No	W/C	Yes/No	No	No	ST	No	No

Notes: 1: Use the setpoint dial or pushbuttons to adjust the absolute temperature setpoint.
2: An Occupancy Override button is available on NS-xxP and NS-xxL models. Other models allow Occupancy Override through the setpoint adjustment interface.

Unit **Sound** **Controls** **Options**

Options For Model SDR

Apply the following options:

Unit **List Price**

Arrangement

20 ga casing

Access plate

Hanger brackets

Inlet & Outlet Covers

Controls disconnect

Low leak const

Low temp/leak const

Removeable Airflow Probe

Sound attenuator

Skid by floor, area or size

Manual quadrant dampers

Primary fusing of transformer

Secondary fusing of transformer

Transformer

Transformer Number


Primary Voltage

Trans VA


Thermostat

Discharge Air Sensor

After selecting your thermostat, next decide upon whether you require a Discharge Air Temperature sensor. This can be selected by selecting the checkbox to the right of “Discharge Air Sensor”. Note: information is also available here by activating the info bubble to right of this option.



Next, select your vav terminal unit, by clicking on the “Select” icon noted in below graphic screen shot.



Choose your specific sized unit(s), and then Click upon “Save and Return to Schedule”,

Select Cancel Show Diagnostics

Select	Results										Electric Heating				Sound			Radiated Sound Power					Discharge Sound Power					
	Size	Price	Max CFM For Size	Max Design CFM	Min CFM	Inlet S.P. in.wg	Min SP Req. in.wg	Down S.P. in.wg	Heat CFM	EAT °F	Actual LAT °F	Actual KW	EH Amps	Rad NC	Dis NC	Atten. Method	dB	250	500	1000	2000	4000	125	250	500	1000	2000	4000
<input type="checkbox"/>	06	\$1,141	550	500	250	1.00	0.62	0.25	250	55.0	95.0	3.50	29.17	19	16	AHRI-885i	54	48	45	38	32	28	64	59	54	51	44	42
<input checked="" type="checkbox"/>	08	\$1,171	1000	500	250	1.00	0.10	0.25	250	55.0	95.0	3.50	29.17	16	-	AHRI-885i	51	44	43	38	34	27	61	57	52	49	46	43
<input checked="" type="checkbox"/>	10	\$1,222	1600	500	250	1.00	0.03	0.25	250	55.0	95.0	3.50	29.17	-	16	AHRI-885i	51	43	40	34	29	28	63	59	56	50	49	46

* ** signifies a NC value (radiated or discharge) that is less than 15
 * Actual coil APD shown is at max airflow, not heating airflow.

Save and New Save Save and Return to Schedule

Here is summary selection in print out format:

Note highlighted Controller additions of Controller sequence item # SDC-ZEC203, and noted “Factory DDC”, and selected option of “Discharge Air Temperature Sensor”, and additional “Thermostat”, wall sensor, item P7002.

Selection Details

Tag			
Quantity	1		
Attribute	Description	Value	Value Description
acsplate	- Access plate	: no	No access panel
amps	- Heater amps	: 29.17	29.17
arrgmnt	- Unit arrangement	: 1	1 - LH Controls / LH Coil
circamp	- Amps per circuit	: 29.17	29.17
contmeth	- Contactor Method	: 1	Magnetic
contype	- Contactor Type	: 2	Magnetic disconnecting
ctlseq	- Controls	: SDC-ZEC203	SDC-ZEC203_BACnet communication
ctltype	- Control Type	: 7	Factory DDC
Discharge Air Sensor	- Discharge Air Sensor	: yes	Yes
disctype	- Disconnect Type	: 3	Non-fused, door interlocking
ehvolt	- Line Voltage	: 120	120V line volt
Family	- Model	: SDR	Single Duct Variable Air Volume Terminal
fldencl	- Control Enclosure	: elect	Electronic
fusingtype	- Fusing Type	: 3	None
htype	- Heating Type	: 3	Electric heat
kw	- Heater kW	: 3.50	3.50
nocontactor	- Contactors (#)	: 2	2 contactors
Nooftransformer	- Transformer (#)	: 1	1 transformer
nopoies	- Contactor Poles	: 1	1 pole
phase	- Htr Phase	: 1	Single phase
primvolt	- Primary Tfmr V	: 120	120 volt/1 phase
size	- Unit Size	: 10	Size 10
spclinsul	- Fiberglass Options	: 1/2 inch	1/2' Fiberglass
steps	- Steps	: 2	2 steps
thermostat	- Thermostat	: P7002	P7002
Transformer	- Transformer?	: yes	Yes
transize	- Transformer VA	: 50	50 VA transformer


One remaining item to select and order should be the MAP GATEWAY, USER SELECTION TOOL. Largo p/n PC-01-0206.

The MAP GATEWAY is a required tool for field use in setup, adjusting and commissioning of the VAV DDC Controllers. Note: the VAV DDC Controllers should

arrive from the factory configured with their individual VAV parameters and settings of Min/Max CFM and Heating CFM setting, and K-factor to name a few of the factory loaded parameters.

The MAP GATEWAY Tool can and is to be ordered separately from the Web Select PARTS, selection tool.

Product Information: The Mobile Access Portal (MAP) Gateway is a pocket-sized web server that provides a wireless mobile user interface to ZEC510 Factory / Field Controllers, ##7000 Series Thermostats, and Smart equipment Rooftop Units (RTUs). The mobile user interface can be displayed in the browser of a phone, tablet, or computer. The MAP Gateway ships from the factory with a base set of features that allow users to access, view, edit, and override key information from all devices connected on a common BACnet Master-Slave/Token Passing (MS/TP) field bus. The wireless connection on the MAP Gateway allows users to be up to 31m (100 ft. line of sight) away indoors and up to 91 m (300 ft. line of sight) away outdoors. The MAP Gateway can also be permanently mounted, powered with an optional separate power supply and connected to an Ethernet access point for use as remote connection to a MS/TP field bus of devices.



MAP GATEWAY
Largo p/n PC-02-0206

Figure: screen shot from Web Select Parts menu

Here below is a photo showing one way to hook up the Map Gateway to the VAV DDC controller. Also to the right is a screen shot from a smart device of laptop computer, showing example viewing of the VAV controller's parameters. These parameters can be viewed, adjusted, or overridden, via use of the Map Gateway with a smart device.

